

Call Forwarding

Let your calls follow you to another number

Price: \$0.50/mo

How it works: You can program your calls to ring at another number. Each time a call is forwarded, your phone will make one short ring. It can still be used to make outgoing calls.

To "turn on" the service:

1. Lift the handset and listen for the dial tone.
2. Press *72 (On a rotary phone, dial 1172.)
3. Listen for the dial tone.
4. Dial the number where you want your calls forwarded.
5. When the phone is answered, your Call Forward is in effect.

If the line is busy, or there's no answer:

6. Hang up.
 7. Within two minutes, repeat steps 1 - 4 above.
- You'll hear a confirmation tone, to let you know your Call Forward is now working.

To "turn off" the service:

1. Lift the handset and listen for dial tone.
2. Press *73. (On a rotary phone, dial 1173.)
3. Listen for the confirmation tone, then hang up. Your Call Forward is now "off", and calls will ring normally on your phone.

To change the "forward to" number:

1. Turn off Call Forward.
2. Repeat steps 1 - 5 above to turn on Call Forward, entering the new "forward to" number.

CALL FORWARD NO ANSWER

Whenever you can't answer, forward your calls to someone who can.

Price: \$0.50

How it works: If you can't get on the phone, you can be sure that your calls won't go unanswered. You can easily change the forwarding number - even choosing how many times your phone should ring.

To "turn on" the service:

1. Lift the handset and listen for the dial tone.
2. Press *92 (On a rotary phone, dial 1192.)
3. Listen for the dial tone.
4. Dial the number of rings (from 2 to 9) to be allowed before the call is forwarded. Then dial the number where you want your calls forwarded.
5. When the phone is answered, your Call Forward No Answer is in effect.

If the line is busy, or there's no answer:

6. Hang up.

7. Within two minutes, repeat steps 1 - 4 above. You'll hear a confirmation tone, to let you know your Call Forward No Answer is now working.

To "turn off" the service:

1. Lift the handset and listen for dial tone.
2. Press *93. (On a rotary phone, dial 1193.)
3. Listen for the confirmation tone, then hang up. Your Call Forward No Answer is now "off", and calls will ring normally on your phone.

To change the "forward to" number:

1. Turn off Call Forward No Answer (see directions above).
2. Repeat steps above to turn on Call Forward No Answer, entering the new "forward to" number.

Notes: Dial the number exactly as if you are calling directly. For a local number, dial the 7-digit phone number. For a long distance number, dial "1" plus the area code. Or if you have speed calling, you may dial one of your codes instead.

CALL FORWARD REMOTE ACCESS

From any location - turn on, turn off, or change your forwarding number.

How it works:

You can use a touch-tone telephone at another location to change your Call Forward on your home or business phone.

To access your telephone's Call Forward service remotely:

1. Lift the handset and listen for the dial tone.
2. Dial the Call Forward access number provided by your telephone company.
3. After the line rings, listen for the special dial tone.
4. Dial your seven-digit home or business telephone number that has Call Forward.
5. Dial your Personal Identification Number (PIN).
6. Listen for the special dial tone.

You are now ready to change your Call Forward. Proceed with one of the Call Forward functions: Call Forward, Call Forward Busy, Call Forward No Answer